

# IMPORTANT!

# **GOLDEN TEE**<sup>®</sup>


## DIP SWITCH SETTINGS FOR 16x9 HDTV

**BETTER GRAPHICS  
MEANS  
BETTER EARNINGS!**

Check your dip switches and make sure they are set correctly.

A two-minute check could be worth big money!

I/O CARD DIAGRAM FOR ORIENTATION



**Sw201**  
Set For Your Video Card & Connector

1	2	3	4
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OFF	ON	OFF	ON
<b>1080p</b>	<b>720p</b>	<b>720p</b>	<b>720p</b>
<b>HDMI</b>	<b>HDMI</b>	<b>SVGA</b>	<b>SVGA</b>
<small>Zotac 640 Video Card and HDMI Cable are Required</small>	<small>HDMI Cable is Required</small>	<small>VGA Cable is Required</small>	<small>VGA Cable is Required</small>

**Sw200**

1	2	3	4
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OFF	ON	OFF	ON
<b>ALL ON</b>			

**Sw202**

1	2	3	4
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OFF	ON	OFF	ON
<b>16x9 Aspect Ratio</b>			

**Cut out cards to carry with you.**

**IMPORTANT!**  
**GOLDEN TEE**<sup>®</sup>  
DIP SWITCH SETTINGS FOR 16x9 HDTV

**BETTER GRAPHICS  
MEANS BETTER EARNINGS!**

Check your dip switches and make sure they are set correctly.  
A two-minute check could be worth big money!

I/O CARD DIAGRAM FOR ORIENTATION

<b>Sw201</b> Set For Your Video Card & Connector				<b>Sw200</b>	<b>Sw202</b>
1	2	3	4	1	1
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OFF	ON	OFF	ON	OFF	ON
<b>1080p</b>	<b>720p</b>	<b>720p</b>	<b>720p</b>	<b>ALL ON</b>	<b>16x9 Aspect Ratio</b>
<b>HDMI</b>	<b>HDMI</b>	<b>SVGA</b>	<b>SVGA</b>		
<small>Zotac 640 Video Card and HDMI Cable are Required</small>	<small>HDMI Cable is Required</small>	<small>VGA Cable is Required</small>	<small>VGA Cable is Required</small>		

**IMPORTANT!**  
**GOLDEN TEE**<sup>®</sup>  
DIP SWITCH SETTINGS FOR 16x9 HDTV

**BETTER GRAPHICS  
MEANS BETTER EARNINGS!**

Check your dip switches and make sure they are set correctly.  
A two-minute check could be worth big money!

I/O CARD DIAGRAM FOR ORIENTATION

<b>Sw201</b> Set For Your Video Card & Connector				<b>Sw200</b>	<b>Sw202</b>
1	2	3	4	1	1
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
OFF	ON	OFF	ON	OFF	ON
<b>1080p</b>	<b>720p</b>	<b>720p</b>	<b>720p</b>	<b>ALL ON</b>	<b>16x9 Aspect Ratio</b>
<b>HDMI</b>	<b>HDMI</b>	<b>SVGA</b>	<b>SVGA</b>		
<small>Zotac 640 Video Card and HDMI Cable are Required</small>	<small>HDMI Cable is Required</small>	<small>VGA Cable is Required</small>	<small>VGA Cable is Required</small>		